

Important information Please Read Before Using Paints

You have purchased the most advance and most accurate Redline Spectra-flame paint system on the market. Only available through the Redlineshop.com we are sure that you will be totally satisfied. Our system has been build around a urethane paint and if you use our special hardener you should not have to use a clear coat. You will obtain a crystal clear spectra-flame paint that is as "hard as nails" and will not peel off. For more information you can contact us at redlineshop.com

- **Before you paint you should have the proper safety gear. You should always shoot in a well ventilated room and always use an approve respirator. Paint vapors are hazardous to your health.**

- **Our paint is designed to use with an airbrush with about 10 to 20 PSI. It is best to use a moisture trap in your line in areas where there is a lot of moisture in the air.**

- **To clean airbrush use Lacquer Thinner. Our paint is designed to shoot right out of the bottle. For some reason you need to thin down the pain use a urethane reducer. You can use lacquer thinner as a last resort, but is not recommended**

- **If you are using our Redline shop hardener **SH01** mix 6 parts paint to 1 part hardener. You Don't have to be exact. Less will work more is not needed**

- **Our paint is designed to use without having to clear coat. If you want, you can use the clear coat of your choice.**

- **Our paints can be mixed together to achieve any color or shade desired.**

- **For quicker dry time you can bake painted casting at 150 degrees for 2 hours.**

Prepping to paint

- **The casting should be clean as possible. For best results use an automotive paint prep degreaser. Wipe the casting down with a rag with degreaser on it. Otherwise clean the casting with lacquer thinner. Avoid any cleaners with oils in it.**

- **For quicker dry times and a "hard as nails" finish, use our special hardener. Do not mix anymore than you are going to use within a hour. Do not pour paint that has had hardener added to it back into the bottle. All unused paint should be discarded or used that day.**

- **Some colors will take a few more coats than others. Most of the time you will need about 4 coats of paint. Your first two coats should be light misting coats. Do this until you have a solid coat of paint. This breaks the surface tension and will prevent paint-less dimples on the surface. This is the most common problem when shooting specraflame paint. These are little spots where the paint will pool away from. If this happens you have not cleaned the casting well enough and/or have sprayed too much paint on your first two coats.**

- **Clean airbrush after each use. If you leave the paint mixed with hardener in the air brush over night you will have to discard your air brush.**

- **For more paint tips or trouble shooting visit redlineshop.com**

